Textile
100 White
262 Gold yellow opaque
388 Bright red opaque
376 Purple
541 Sky blue opaque
665 Spring green
432 Terra
225 Honey
746

Black opaque

256

Reflex yellow

126 White opaque 235 Orange

360 Oriental red

548 Blue violet

511 Cobalt blue 667

Spring green opaque

437 Terra opaque

434 Sienna

800 Silver

257 Reflex orange Provence yellow

263 Orange opaque

> 350 Fuchsia

549 Blue violet opaque

> 603 Turquoise

620 Olive green

Skin colour

427 Havanna brown

Gold

384 Reflex rose

253 Gold yellow

387 Bright red

375 Bordeaux

527 Sky blue

685 Turquoise opaque

> 684 Bottle green

227 Yellow ochre

700 Black

814 Antique gold

> 672 Reflex green

Packaging

Decorfin Textile:

40 colours in bottles of 16 ml and 50 ml



Set

For a first acquaintance with Decorfin Textile. Complete with a booklet with tips and ideas.

No. 07821608, with 6 bottles and 2 brushes



More information

The Talens website is packed with information on all types of Decorfin paint and related products. You can find us at www.royaltalens.com. In addition there are leaflets on the other Decorfin paint types: Universal Satin, Glass and Porcelain. You will also find in the Decorfin range products for special effects like Antique Colour and Patina.



Royal Talens P.O. Box 4, Apeldoorn, NL 88700024 2011 www.royaltalens.com









Textile: ready to use!

A water-based textile paint for use on washed cotton, linen and most mixed fibres. The colours retain their colourfastness and softness to the touch even after repeated washing.

Features

- A water-based hobby paint for decorating, printing and stencilling fabrics.
- Ample choice of colours: 40 opaque colours, 10 of which can also be used on dark-coloured fabrics. The colours are ideal for mixing with each other. Silver and (Antique) Gold are best used pure.
- Textile "opaque" colours are as effective on light as on dark-coloured surfaces. Textile "transparent" colours are only opaque on light-coloured surfaces; on dark-coloured surfaces they are transparent.
- The paint dries in about 2 hours. After fixing the paint the
 material can be washed. To preserve the glow of the colours
 Silver and Gold and the opaque colours for as long as
 possible, wash the painted material at a maximum of 40 °C;
 the other colours can be washed at 60 °C. For a result that
 retains its beauty, you can fix the decoration by ironing (see
 below).

Decorating, washing and fixing

- Before applying the paint, first wash the material (following washing instructions). This washes the dressing out of the material so that the paint adheres better.
- Lay a piece of cardboard under the material. This prevents the paint leaking onto the working surface. Stir the paint well before use.

- The paint must be fixed. This means that after the paint has dried the
 decoration must be "pressed" firmly with an iron on the reverse side
 (25 x 25 cm at a time) following the instructions on the wash label.
 In this way the colours will have optimum adhesion and can be washed.
- You can apply the paint with a soft-haired Decorfin brush. But you can also use stippling brushes.

Tips

- · Close bottles tightly after use and clean tops thoroughly.
- Brushes will remain in good condition for a long time if they are cleaned immediately after use with soap and water. After cleaning place them in an empty jar with the bristles facing upwards.
- If you are not going to use the paint for some time, put a teaspoonful of water in the bottle. This will prevent the paint from drying out.
- For the best painting results with Decorfin Glass use special Decorfin brushes, like series 61 en 62.





- You can decorate a very wide variety of materials with Decorfin Textile. Cotton T-shirts, cushions, curtains, table napkins, duvet covers, a banner, a cap or sneakers.
- The colours suit all interiors.
 The bright reflex and metallic colours are most effective when used pure.





